

SERIE CORNER-K

CORNER-K SERIES



CR31 - CR32 - CR33 - CR34 - CR35 - CR36 - CR37 - CR38 - CR39

1) Uscire la poltrona dalla scatola.

1) Extract the armchair from the box

