

SERIE FLAG

FLAG SERIES



FL35C - FL35N - FL37C - FL37N - FL38C - FL38N

FL63C - FL63N - FL65C - FL65N - FL66C - FL66N

FL23C - FL23N - FL25C - FL25N - FL26C - FL26N

FL53C - FL53N - FL55C - FL55N - FL56C - FL56N

FL45C - FL45N - FL47C - FL47N - FL48C - FL48N

1) Uscire la sedia dalla scatola.

1) Extract the chair from the box

